

PANDJIRIS, INC

5151 Northrup • St. Louis, MO 63110 • (314) 776-6893

SERIES 1600 MANIPULATOR Options and Accessories

For column or boom addition, add per foot
For column or boom deletion N/C

For Power Cable Track for Column and Boom (For sizes other than 16x16, Consult Factory)

For free standing base

Preset digital tachometer in manipulator joystick hand pendant, reads in IPM or CmPM, for boom

For variable speed hoist, 2 to 46 IPM

For "Step-Over" control, allows indexing of boom movement for overlay operations etc.

For flashing red light at column top and boom end with audible alarm

For special voltages, add Consult Factory

Power rotation of column for special applications, variable speed at .004 to .12 RPM

For support platform bolted to column for welding power source:
Standard 40x42 for single head mounting
Oversized 44x60 for multiple head mounting

For turntable to support wire drum or reel payoff (requires platform listed above)

For gas bottle holder bracket, supports two bottles

For 1-1/2 H.P. Flux recovery unit - installed (including hose), add Consult Factory

For 3 H.P. Flux recovery unit - installed (including hose), add Consult Factory

For 5 H.P. Flux recovery unit - installed (including hose), add Consult Factory

For 7-1/2 H.P. Flux recovery unit - installed (including hose), add Consult Factory

For operator's seat

WELD EQUIPMENT MOUNTING CHARGES

Pandjiris will mount and integrate welding head and control packages on the above manipulator. The configuration of the mounting will typically include installation of the wire drive, torch wire reel, flux hopper, wire drive control, and connection of all cables and hoses between the power source and wire feed control required for proper operation. Other accessories such as AVCs, slides, swivels etc. can also be mounted for an extra charge.

To Mount a Single Wire SUB-ARC package
To Mount a Twin Wire SUB-ARC package
To Mount a Tandem SUB-ARC package
To Mount a MIG package
To Mount a Cold Wire TIG package
To Mount a Fusion TIG package
To Mount an AVC with the above TIG packages

To Mount a dual axis seam tracker

To Mount wire reel at aft end of boom with insulated wire guide conduit running the length of the boom, add per foot of boom stroke

Terms: Pandjiris, Inc. standard terms and conditions apply, f.o.b. Factory, St. Louis, Missouri, or designated ship point.

Delivery: Consult Factory

PRICE LIST

For Bulletin No. : MANP 393-1
Effective Date : January 2014
Page Number : D-12